# OLIGHT
# USER MANUAL

## IN THE BOX

Warrior 3S (with Battery)

USB Magnetic Charging Cable

Holster

Insulating Film
Remove the insulating film

## SPECIFICATIONS

| | | | | | |
|---|---|---|---|---|---|
| TURBO | 1,800 lm | 1,800 cd | 1:00 | 0.5 m | 0.5 m |
| HIGH | 1,000 lm | 1,000 cd | 2:00 | 1.0 m | 1.0 m |
| MED | 350 lm | 350 cd | 5:00 | 2.0 m | 2.0 m |
| LOW | 100 lm | 100 cd | 10:00 | 3.5 m | 3.5 m |
| MOON | 1 lm | 1 cd | 30:00 | 15.0 m | 15.0 m |

| | | | | |
|---|---|---|---|---|
| TURBO | HIGH | MED | LOW | MOON |
| 300cm | 100cm | 50cm | 25cm | |

| | | | | |
|---|---|---|---|---|
| 1.5m | 23,000cd | IPX8 | IÖ:IP68 | IÖ:IP67 |
| | | | IL:IP-68 | IL:IP-67 |

| WATER | AIR | FIRE | EARTH | STH |
|---|---|---|---|---|
| TITANIUM | TITANIUM | TITANIUM | TITANIUM | PURE COPPER |

| | | | | |
|---|---|---|---|---|
| 27h/27Wh | 27h/27Wh | 27h/27Wh | 27h/27Wh | 30h/30Wh |
| 2.5h/2.5Wh (Battery Saver) | 2.5h/2.5Wh (Battery Saver) | 2.5h/2.5Wh (Battery Saver) | 2.5h/2.5Wh (Battery Saver) | |

** All above specifications are test results based on ANSI/NEMA FL1-2009 Standard. The tests are performed using the battery included in the flashlight.*
*Note: The maximum output brightness will decrease as the battery voltage decreases.*

## BATTERY INSTALLATION

Before first use, please unscrew the tailcap and remove the insulating film. If the battery needs to be replaced, make sure that the positives of the new battery faces the flashlight head when you put it in.

## USB MAGNETIC CHARGING CABLE — MCC3

| Parameter | Specification |
|---|---|
| Charging cable | USB type A – magnetic charging connection, length: 0.1m |
| Input | USB A – Type DC 5V 2A |
| Charging pattern | CC&CV |
| Maximum charging current | 2A |
| Voltage of fully charged battery | 4.2V ± 0.05V |
| Time to fully charge | 5.5 hours (For reference only. When the USB power supply is the same as the battery charger power capacity, the charging time will be longer) |
| Charge indication | Green: full over 95% or disconnected with flashlight |

## CHARGING

**Built-in Proximity Sensor**

**Level 3 or Higher Brightness**

RED
Charging

GREEN
Complete Charge

## AVAILABLE BATTERIES

- 1 x customized 5000mAh 21700 rechargeable lithium battery

## INDICATORS ON BOTH SIDES

| Brightness Level Indicators | Battery Level Indicators |
|---|---|
| Turbo | ≥ 75% |
| High | 50%~75% |
| Medium | 25%~50% |
| Low / Moonlight | 10%~25% |

**NOTE:** While the light is on, if the battery power is less than 10%, the lowest indicator on the right side will glow red.

## PROXIMITY PROTECTION FUNCTION

When the light is on and set at level 3 or higher brightness, if the front lens proximity sensor detects an obstruction nearby, the brightness will automatically reduce. The brightness will restore when the obstruction is gone. The light will turn off directly if the blockage continues for more than 1 minute.

To disable the proximity sensor, please quickly double click or triple click the switch within 5 seconds after the automatic dimming. Then, the brightness will restore to the normal level. Turning off the light can re-activate the proximity sensor.

## WARRIUR 3 S
(LIMITED EDITION)

Thank you for purchasing this Olight Product. Please read this manual thoroughly before use and keep it for future reference!

## DANGER

- DO NOT shine the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT cover the flashlight's head or place the head on the ground when the flashlight is on. Re-radiation energy may cause damage to the flashlight head or even ignite the surrounding of flammable objects nearby.
- The battery can only be charged while installed in the flashlight.

## WARNING

- DO NOT activate turbo mode repeatedly under high temperature to prevent the flashlight body from overheating and burning. (Turbo: 2 min. Cool down: 10 min.)
- DO NOT use Non-protected rechargeable batteries.
- DO NOT use the battery if the wrapper is broken, or if any other compromised cases.
- Please lock out the switches if the flashlight is left unused, carried, or transported. The hard lock-up due to accidental activation may melt the lens of the flashlight, cause close objects to burn, or even result in unexpected disasters.
- Stop using the battery with care if the battery needs to be changed, please take good care of the battery taken out. Do not mix it with the conductive metals.

## ATTENTION

- The built-in sensor may NOT work if the lens is blocked by water or oil or dirty lenses. Please keep the lens clean to ensure that it works properly.
- Please protect the surface of the front lens carefully. If there is any damage on the surface of the front lens, the light output may be automatically decreased by 50%.
- While pressing and holding the tail switch or the magnetic remote switch to momentarily access high, turbo, or moonlight, if the battery power is low, the brightness will automatically reduce. The light will turn off automatically if the obstruction continues for more than 1 minute.

## NOTICE

- When the flashlight is turned off, the control circuit will be memorized. The modes that can be memorized are: moonlight, low, medium, and high mode (after the light is turned off, high mode will be memorized if it was last used before the moonlight mode). Strobe and turbo mode cannot be memorized.
- Unscrew the tailcap and the battery will cut off the power to the flashlight. Please take good care of the battery taken out. Do not mix it with the conductive metals.
- Please keep the lens free with alcohol or any other chemicals.

## NOTICE

- When the flashlight is turned off, the control circuit will be memorized. The modes that can be memorized are: moonlight, low, medium, and high mode (after the light is turned off, high mode will be memorized if it was last used before the moonlight mode). Strobe and turbo mode cannot be memorized.
- Unscrew the tailcap and the battery will cut off the power to the flashlight. Please take good care of the battery taken out. Do not mix it with the conductive metals.
- Please keep the lens free with alcohol or any other chemicals.

## TAIL SWITCH

The flashlight produces different output settings by pressing lightly or hard on the tail switch (please refer to the following program configurations).

## TWO DIFFERENT PROGRAM CONFIGURATIONS

**CONFIGURATION 1 (FACTORY DEFAULT SETTING):**
Simple press the tail switch (press and release quickly) to turn the light on/off.
Press and hold the tail switch for momentary on. Release to turn off.

**CONFIGURATION2:** Half press for Turbo, hard press for Strobe, release switch to turn the flashlight off.

## SWITCH BETWEEN DIFFERENT PROGRAM CONFIGURATIONS

Switch between configuration 1 and configuration 2: by pressing hard then holding tail switch and single press on side switch at the same time. when you release tail switch, the Configuration will be selected.

# CONTENTS


(EN) English ..... 01
(CN) 简体中文 ..... 02
(FI) Finish ..... 03
(NO) Norwegian ..... 04
(SV) Svenskt ..... 05
(NL) Nederlands ..... 06
(PL) Polska ..... 08
(DE) Deutsch ..... 09
(HU) Magyarország ..... 11
(RU) Русский ..... 12
(ES) Español ..... 14
(RO) Romanesc ..... 15
(UA) Ukrainian ..... 17
(JP) 日本語 ..... 18
(KR) 한국어 ..... 20
(TH) ไทย ..... 21
(FR) Français ..... 22
(IT) Italia ..... 23
(SK) Slovenskýjazyk ..... 25
(CS) Čeština ..... 26


## (EN) English

### HOW TO OPERATE

### SIDE SWITCH

**ON/OFF:** Single click the side switch to turn the light ON/OFF. When the light is turned on again, it will return to the last used mode/output.

**CHANGE BRIGHTNESS LEVEL:** When the flashlight is on, press and hold the side switch and it will, starting from the current brightness level, automatically cycle through Low, Medium, and High mode. The mode you selected when the side switch has been released. (Please note: moonlight, turbo and strobe are not in the cycle mode.)

**MOONLIGHT MODE:** When the flashlight is off, press and hold the side switch for over one second to access the moonlight mode. When released mode is moonlight, simply click the switch to access it.

**TURBO AND STROBE:** Quick click or side switch to enter into Turbo, double click again to return. If memory mode were High or Medium, the output is Medium. Triple click to access Moonlight, the output is memory mode.

**STROBE:** Quick triple click the side switch to enter the strobe mode. To quit this mode, single click or press and hold the side switch.

**LOCK/UNLOCK:** When the flashlight is off, press and hold the side switch (for about 2 seconds) to access the button lockout mode. Flashlight will ear one the moonlight mode first and then switch off to signal the lockout mode. In lockout mode, if you press and hold the side switch for less than one second or use the tail switch, the indicator light of the switch will light up red at the lowest level for two seconds to signal that the light is still in lockout mode. To unlock it, keep the side switch pressed for one second until the moonlight mode is on again.

### TAIL SWITCH

The flashlight produces different output settings by pressing lightly or hard on the tail switch (please refer to the following program configurations).

### TWO DIFFERENT PROGRAM CONFIGURATIONS

**CONFIGURATION 1 (FACTORY DEFAULT SETTING):** Simple press the tail switch (press and release quickly) to turn the light on/off.
Press and hold the tail switch for momentary on. Release to turn off.

**CONFIGURATION2:** Half press for Turbo, hard press for Strobe, release switch to turn the flashlight off.

### SWITCH BETWEEN DIFFERENT PROGRAM CONFIGURATIONS

Switch between configuration 1 and configuration 2: by pressing hard then holding tail switch and single press on side switch at the same time. when you release tail switch, the Configuration will be selected.

## (CN) 简体中文

### 操作说明

### 侧按键

**开/关机：**单按开、关机。开机时，手电会恢复到关机前的状态。

**注：模式记忆：**通过侧按键设置或进入的月光模、低档、中档、高档状态手电关机，记忆这(高档仅记忆1分钟后的为中档)，作为下次侧按键开机时默认状态。爆闪与频闪模式不记忆。

**改变亮度：**开机状态下，长按按键，输出从（从当前亮度开始）低档、中档、高档循环变化，松开按键，输出所在（当前亮度）档位。爆闪不在调光循环序列里。

**开启月光模：**关机状态下按住按键1秒以上，开启月光模，松开按键，手电以月光模式工作。单按按键，

**直接开启最亮：**快速双按按键进入极亮模式，再次双按退回，如记忆状态为高档或中档，输出中档，如记忆状态为低档或月光模，输出记忆状态。

**闪烁：**快速连按三次（或以上）进入爆闪，单按或长按按键退出爆闪模式。

**锁键与解锁：**关机状态下，按住按键（约2秒）直至锁键模式，手电会发出一个月光模式，在锁键状态下，长按按键超过1秒钟或单击开关，锁键状态下，手电开启，按键周围的指示灯会以最低亮度红色闪烁两秒以示锁键状态。要解锁，请按住按键直到手电开启。

### 尾按键

手电会根据按键开关，手电输出不同的模式（参阅下文程序配置）。

**手电尾按开关程序配置：**

**配置1(出厂默认)：**轻按按键(快按)，单按开关手电开关。按住按键，手电开启，松开按键，长按按键保持，手电开启，按键释放时手电关闭。

**配置2：**轻按按键半按手电，重按按键(按键)，按键释放时手电关闭。

**配置程序转换：**

按住侧按键，单击一次侧按键，手电关闭。

**LEZÁRÁS / FELOLDÁS:** A kikapcsolt lámpatest lövő lámpán tartva nyomva az oldalról kapcsolót 2sec. 2 másodpercig! a lámpa leszkárolása! Ez lezárás (szemben az élős jelzőlevél a lámpa erőcsöt beállítottuk szemben 8L maglá kapcsolt). A lezárt lámpatest lövő lámpán az oldalról kapcsolót nyomva tartva (legalább egy rövid ideig) nyomva tartásakor vagy a hátsó zárásakor lövő lámpán az oldalról kapcsolót nyomva tartva (legalább egy rövid ideig) a lámpa feloldja a lámpa a lezárt lámpa. A lámpa ugyanolyan módban és fényerőszinten kezd el dolgozni, amilyen a lámpa utoljára volt kikapcsolva. Ez a funkció nem szerepelhet az ismétlődő villogó és a turbó módban.

**MOONLIGHT MODE:** A kikapcsolt lámpatest lövő lámpán tartva nyomva az oldalról kapcsolót egy másodpercig a holdfény módban. Amikor az elengedett fokozat holdfény, az egy egyszerű kattintás a kapcsolót.

**TURBÓ ÉS STROBÓ:** Gyors kattintás az oldalsó kapcsolóra a turbó ugrás, kettős kattintás ismét a kikapcsolás. Ha az memóriamód volt a magas vagy a közepes, a kimenet a közepes. Hármas kattintás a Holdfény, a kimenet az memóriamód van.

**STROBÓ:** Gyors hármas kattintás az oldalsó kapcsoló a stroboszkóp mód. A kilépéshez nyomja meg a kapcsolót.

**TURBÓ ÉZTEMENDŐ ÉS VISSZAKAPCSOLÁS:** A lámpa az alacsony szinten van bekapcsolva. A turbó üzemmód az ideiglenes turbó üzemmódba lép. Az oldalkapcsoló újabb gyors kattintott megnyomásakor megfordítják a visszakapcsolás. Ha az elemettel fokozat High (erős) vagy Medium (közepes), a fényerőszkszot Medium (közepes) lesz. Ha Low (alacsony) vagy Moonlight (holdfény) a memória mód, a fényerőszkszot a memória mód szerinti lesz.

**STROBOSZKÓP:** Az oldalkapcsoló háromszori gyors egymás utáni lenyomásával a lámpa stroboszkóp üzemmódba áll. A stroboszkóp üzemmód kikapcsolásához nyomja meg egy egyszer, vagy tartsa nyomva az oldalsóról.

**LEZÁRÁS / FELOLDÁS:** A kikapcsolt lámpatest lövő lámpán tartva nyomva az oldalról kapcsolót (kb. 2 másodpercig) a lámpa leszkárolása! Ez lezárás (szemben az élős jelzőlevél a lámpa erőcsöt beállítottuk 8L maglá kapcsolt). A lezárt lámpatest lövő lámpán az oldalról kapcsolót nyomva tartva (legalább egy rövid ideig) nyomva tartásakor vagy a hátsó zárásakor lövő lámpán az oldalról kapcsolót nyomva tartva (legalább egy rövid ideig) a lámpa feloldja a lámpa a lezárt lámpa. A lámpa ugyanolyan módban és fényerőszinten kezd el dolgozni, amilyen a lámpa utoljára volt kikapcsolva. Ez a funkció nem szerepelhet az ismétlődő villogó és a turbó módban.

**MOONLIGHT MODE:** A kikapcsolt lámpatest lövő lámpán tartva nyomva az oldalról kapcsolót egy másodpercig a holdfény módban. Amikor az elengedett fokozat holdfény, az egy egyszerű kattintás a kapcsolót.

**TURBÓ ÉS STROBÓ:** Gyors kattintás az oldalsó kapcsolóra a turbó ugrás, kettős kattintás ismét a kikapcsolás. Ha az memóriamód volt a magas vagy a közepes, a kimenet a közepes. Hármas kattintás a Holdfény, a kimenet az memóriamód van.

**STROBÓ:** Gyors hármas kattintás az oldalsó kapcsoló a stroboszkóp mód. A kilépéshez nyomja meg a kapcsolót